Bridgeport Mill Standard Operating Procedure (SOP)

Do not use the machine if there is a part mounted! Ask the PIT crew about the machine status.

Starting the mill:

- 1. Perform a visual inspection of the machine. Make sure all components are set tight. Check the service disconnect, flip to on position.
- Report any damage to the mill or loose parts to the PIT crew immediately.Do <u>not</u> start the machine.
- 3. Set up your work piece and tools and demo your operations to check for collisions, adjust if necessary.
- 4. Unlock the spindle break.
- 5. Start the machine.

Working with the machine:

- 1. Always double check your set-up in between steps.
- 2. Never leave a wrench mounted on the draw bar.
- 3. If you need to pause your job, turn off the spindle.
- 4. Make sure that the way lock levers are loose during travel.
- 5. When resuming your job, check your set-up again.

Shutting down the Bridgeport:

- 1. Turn off the spindle and power down the machine (service disconnect).
- 2. Clean the tools and put them away. Clean shavings from the table, slides and bed and wipe off oil and coolant.
- 3. Put larger amounts of shavings in the proper shavings bucket.
- 4. Remove your work piece. Place residual materials in the material storage cart.
- 5. Clean and organize the tool cart.
- 6. Sweep the mill area shop floor.
- 7. Let the PIT crew know when you are done.